Flexem Flexem □□ Series Service Manual

F5-MD0008N

1. Description

F5-MD0008N

3. Product Information

F5-MD0008N

Hardware

24VDC Input N/A

Transistor Output 8

Signal Indicator Available

Power Supply 24VDC -15%/+20%, maximum of 3.2W. Provided internally in the main unit, no external input required

Wiring Structure Detachable terminal block

Usage Cannot work independently, must be used in conjunction with FL5/FC5 series main units

Environmental

Operating Temperature -10℃~60℃

Storage Temperature -20℃~70℃

Environmental Humidity 5~95%RH (non-condensing)

Mechanical

Installation Directly installed on DIN 46277 rail (width 35mm) or fixed with screws

Dimensions 40mm×90mm×83mm

□□□□ 8□

□□□□ NPN(PNP)

□□□□ 24VDC

□□□□ 19.2~28.8VDC

□□□□ 0.5A

□□/□ 0.5A*□□□□□□□

□□ □□1VDC

□□□□□□ <5μA

□□□□□□□ 2.4W

□□ □

□□□□ □□34μs

□□□□ □□250μs

□□□□□□ 1KHz

□□□□ □

□□□□□□□□ 1.3A

□□□□□□□□□ □10ms

□□□□ □□ 39VDC□±1V

□□ □□□□□□□□500VAC

□□□□□ □□□

□□□□ □□□50m

□□□□ □□□□□□

www.autronexa.com